Dayton 1/2 ton hoist manual

Continue

1 Operating nstructions and Parts Manual 3YB72 thru 3YB99 and 3Y10 thru 3Y15 and ZY5 thru 3YB99 and 3Y10 thru 3YB99 and 3Y10 thru 3YB99 and 3Y10 thru 3Y15 and zY5 thru 3YB99 and 3Y10 thru 3YB9 in personal injury and/or property damage! Retain instructions for future reference. Dayton lectric Chain oists that provide quick, precise lifting. The hoists are constructed of tough, but lightweight, die cast aluminum alloy housings. An oil bath transmission, equipped with heattreated, alloy steel gears and an overload limiting clutch, provides smooth and reliable operation. With a pushbutton station that fits comfortably in one hand, the operator can safely control the hoist while the other hand is free to quide the load. The electrical controls, which are readily accessed under the electrical cover, utilize quick-connect terminals for easy voltage conversions and a 2V control circuit for added safety. Other features that ensure the safe operation of Dayton electric chain hoists include a magnetic disc brake that delivers sure stopping and secure holding of the load. Adjustable upper and lower limit switches regulate the load travel. For additional safety, a chain stop is attached to the slack end of the load chain. Dayton electric chain hoists are designed and tested in accordance with the American ociety of Mechanical ngineers Code B30.16, afety tandard for Overhead oists. oists are built in compliance with the American ociety of Mechanical ngineers Code B30.16, afety tandard for Overhead oists. nduction Motor Aluminum ousing Jam-Resistant Chain uide Form 5877 igh Quality teel Chain nclosed oad Block atch-type ook Figure 2 lectric oist Construction Chain top Adjustable imit witches eat-treated mooth-running teel ears train Cable in Control Cord 2V Pushbutton Control tation Printed in U...A /02/VCPVP lectrical Connections All at One nd for asy Changes Figure 1 - lectric Chain oist Table of Contents CTO PA Description...1 Warnings...2 pecifications...3 eneral afety nformation...5 Operation...6 Troubleshooting Chart...7 Maintenance Check ist...16 Repair Parts ist...18 Warranty...32 Dayton Operating nstructions and Parts Manual 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Dayton lectric Chain oists Warnings ach Dayton lectric Chain oist is built in accordance with the specifications contained herein and applicable sections of the *American ociety of Mechanical ngineers Code B30.16 Overhead oists, the ational lectrical Code (A/FPA 70) and the Occupational afety and ealth Act. ince OA states the ational lectrical Code applies to all electric hoists, installers are required to provide current overload protection and grounding in keeping with the code. Check each installation for compliance with the application, operation and grounding in keeping with the code. Department, 22 aw Drive, Box 2300, Fairfield, J, U.A. mproper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in death or serious injury. To avoid such a potentially hazardous situation, the operator must observe the following precautions: 1. DO OT operate a damaged, malfunctioning or unusually performing hoist. 2. DO OT operate the hoist until you have thoroughly read and understood this Operating nstructions and Parts Manual. 3. DO OT use hoist with twisted, kinked, damaged, or worn load chain. 6. DO OT use the hoist to lift, support, or transport people. 7. DO OT lift loads over people. 8. DO OT operate a hoist unless all persons are and remain clear of the supported load. 9. DO OT operate unless load chain. 11. Protect the hoist s load chain from weld splatter or other damaging contaminants. 12. DO OT operate hoist when it is restricted from forming a straight line from hook to hook in the direction of loading. 13. DO OT use load chain as a sling, or wrap load chain around load. 1. DO OT apply the load to the tip of the hook or to the hook latch. 15. DO OT apply the load unless load chain is properly seated in the load sheave(s). 16. DO OT apply load if bearing prevents equal loading on all load supported by the hoist unattended unless specific precautions have been taken. 19. DO OT allow the load chain or hook to be used as an electrical or welding ground. 20. DO OT allow the load chain or hook to be touched by a live welding electrode. 21. DO OT remove or obscure the warnings on the hoist. 22. DO OT operate a hoist unless it has been securely attached to a suitable support. 2. DO OT operate a hoist unless load slings or other approved single attachments are properly sized and seated in the hook saddle. 25. Take up slack carefully - make sure load is balanced and load holding action is secure before continuing. 26. hut down a hoist that malfunctions or performs unusually and report such malfunction. 27. Make sure hoist limit devices function properly. 28. Warn personnel of an approaching load. 29. Maintain a firm footing or be otherwise secured when operating the hoist. 30. Check brake function by tensioning the hoist, etc. under slack conditions only. 32. Make sure the hook latches are closed and not supporting any parts of the load. 33. Make sure the load is free to move and will clear all obstructions. 3. Avoid swinging the load or hook. 35. Make sure hook travel is in the same direction as shown on the controls. 36. nspect the hoist regularly, replace damaged or worn parts, and keep appropriate records of maintenance. 37. Use rainger parts when repairing the unit. 38. ubricate load chain per instructions in this manual. 39. DO OT use the hoist s overload limiting clutch to measure load. 0. DO OT use the hoist s limit switches as routine operating stops. They are emergency devices only. 1. DO OT allow your attention to be diverted from operating the hoist s. 2. DO OT use the hoist to be subjected to sharp contact with other hoists, structures, or objects through misuse. 3. DO OT adjust or repairs. 23 Dayton Operating nstructions and Parts Manual Models 3YB92 thru 3YB91 and 3YB96 thru 3YB99, 3Y10 pecifications for 1-peed Models Power Chain Control Min. Dist. upply Motor ow ift Cord ift Between ousing Dimensions Model Req. P Voltage * ength ength peed ooks W D 1/ Ton 500 lb. Capacity (227 kg) 3YB72 115/230V 1/ / / 8 1 Phase 3YB96 115/230V 1/ / / 8 1 Phase 3YB96 115/230V 1/ / / 8 1 Phase 3YB96 115/230V 1/ / / 8 1 Phase 3YB99 115/230V 1/ / / 8 1 Phase 3YB96 115 1 Phase 1/2 Ton 1000 lb. Capacity (5 kg) 3YB78 115/230V 1/ / /8 1 Phase 3YB85 115/230V 1/ / / ///8 1 Phase 3YB80 230/60V // /8 3YB86 230/60V // /8 3YB86 230/60V // /8 3YB86 230/60V / 8 11 // /8 1 Phase 3YB87 115/230V / 8 11 // /8 1 Phase 3YB82 230/60V / 8 11 // /8 1 Phase 3YB87 12/230V / 8 11 // /8 1 Phase 3YB87 12/230V / 8 11 // /8 1 Phase 3YB87 12/230V / 8 11 // /8 1 Phase 3YB87 12/230V / 8 11 // /8 1 Phase 3YB87 115/230V / 8 11 // /8 1 Phase 3YB87 115/230V / 8 11 // /8 1 Phase 3YB87 12/230V / 8 11 // /8 1 Phase 3YB87 115/230V / 8 11 // /8 1 Phase voltage is 1/2 that of the low voltage. At full load, it is not unusual for the hoist to draw in excess of the motor amperage listed. The 1 hp, 115/230V models must have a dedicated power circuit rated for at least 20A, 125V when they are wired for 115V. t is recommended to use 230V on the 115/230V models when it is available. 34 Dayton Operating nstructions and Parts Manual 3YB92 thru 3YB95 and 3Y11 thru 3Y15 Dayton lectric Chain oists pecifications for 2-peed Models (ingle Voltage Motor Only) Power Motor Amps * Chain Control ift Min. Dist. upply P ift Cord peed Between ousing Dimensions Model Req. (fast/slow) (fast/slow) ength ength (fast/slow) ooks W D 1/2 Ton 1000 lb. Capacity (5 kg) 3YB92 60V.5/.17.88/ ft 6 ft 16/5.3 FPM 18" 8 11 /16" 25" 3YB93 60V.5/.17.88/ // Y11 60V.5 nformation This hoist is intended for general industrial use for lifting and transporting freely suspended material loads within its rated capacity. Prior to installation for abnormal environmental or handling conditions and to observe the applicable recommendations as follows: ADVR VROMTA CODTO Do not use the hoist in areas containing flammable vapors, liquids, gases or any combustible dusts or fibers. Refer to Article 500 of the ational lectrical Code. Do not use this hoist in applications involving extended exposure to ambient temperatures below -10 F or above 130 F. FT OF AZARDOU OAD This hoist is not recommended for use in lifting or transporting hazardous loads or materials which could explode or create chemical or radioactive contamination if dropped requires failsafe redundant supporting devices which are not incorporated into this hoist. FT OF UDD OAD This hoist is not recommended for use in the lifting of guided loads, including dumbwaiter installations.5 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3Y15 eneral afety nformation 1. Follow all local electrical and safety codes, as well as the ational lectrical Code (C) and the Occupational afety and ealth Act (OA) in the United tates. 2. oist must be securely and adequately grounded. oist power cable is provided with an additional lead (green) for grounding purposes. Always disconnect power source before working on or near a hoist or its connected load. f the power disconnect point is out-ofsight, lock it in the open position and tag to prevent unexpected application of power. 3. Be careful when touching the exterior of an operating motor; it may be hot enough to be painful or cause injury. With modern motors this condition is normal if operated at rated load and voltage (modern motors are built to operate at higher temperatures).. Protect the power cable and control cable from coming in contact with sharp objects. 5. Do not kink power cable and control cable and never allow the cable to come in contact with oil, grease, hot surfaces, or chemicals. 6. Make certain that the power source conforms to the requirements of your equipment. 7. nspect the unit daily before operating hoist. 8. Cluttered areas and benches invite accidents. 9. The operator should not engage in any practice which will divert his attention while operating the hoist. 10. Before using the hoist, the operator should be certain that all personnel are clear. 11. Do not operate hoist with loads exceeding its rated capacity. 12. upporting frames or beams used as a hoist hanger must have a greater load capacity than the hoist. 13. Do not attempt to operate hoist beyond normal maximum lift range. 1. Align hoist for a straight line pull. Avoid side pull or end pull. 15. Do not operate hoist with twisted or damaged chain. 16. Do not use hoist to lift people or to carry loads over people. 18. Do not leave a load suspended in the air unattended. 19. Always remove load before making repairs. 20. Do not remove or obscure capacity or warning decals. nstallation 1. Before installing the hoist, check the following: a. Make sure all supporting structures and attaching devices are strong enough to hold your intended loads. f in doubt, consult a qualified structures and attaching the hoist, check the following: a. Make sure all supporting structures are strong enough to hold your intended loads. f in doubt, consult a qualified structures and attaching devices are strong enough to hold your intended loads. the hoist as recommended in the ational lectrical Code. c. Power supply should be plus or minus 10% of the voltage specified on the motor nameplate. t is critical to use adequately sized power cables, especially with 1-phase hoists (ee Power upply Precautions, page 15). Be sure dual voltage hoists are connected or wired to correspond with your power supply (ee Figures 11A, 11B, and 11C). d. The installation area must provide safe operator, including sufficient room for the load at all times. e. For installations where the slack chain hanging from the unit may be objectionable or hazardous, the use of a chain container is recommended. ee TAATO OF CA COTAR AMBY. 2. Before operating the hoist, be sure to observe the following: a. AWAY DCOCT OT FROM POWR UPPY before removing electrical cover or when making any electrical cover or when making any electrical cover or when making any electrical cover of the power cable should always be connected to a suitable ground by means of a screw or clamp. An alligator clip does not make a safe ground connections at the power source. Push the UP button and observe the direction of the load block. f it raises, the phasing is correct and permanent connections may be made at the power source. f the load block lowers when the UP button is pushed, release the button immediately since the limit switches will not operate to protect the load hook direction (phasing). Do not change connections in the hoist or pushbutton assembly. d. Make sure load chain is not twisted as it travels into the hoist. 56 Dayton Operating nstructions and Parts Manual 3YB72 thru 3YB99 and 3Y10 thru 3YB72 thru 3YB72 thru 3YB99 and 3Y10 thru 3YB72 thru 3 to pull around corners. f. Read AM-B30.16 afety Code for oists. 3. ubricate the chain if necessary, (ee UBRCATO, page 12).. Before placing the hoist until the load hook nears the required stopping point and inch into that point. f either setting is incorrect, adjust according to MT WTC ADJUTMT, page 11. TAATO OF CA COTAR AMBY (OPTOA ACCORY) Refer to Figure Remove retaining clip and attachment pin and let the slack end of chain in chain container. Do not remove the chain stop. 3. Place chain container flush against housing with chain stripper between top lugs. nsert long attachment pin and replace retaining clip.. Feed the remainder of chain into container by hand Do not allow load to come in contact with the chain container. f this situation exists, reset the UP limit switch (ee MT WTC ADJUTMT, page 11) so that the hook block stops below the chain container. Operation OVROAD MT PROTCTO This hoist is equipped with a factorycalibrated overload limiting clutch that will permit the lifting of loads within its rated capacity, but will prevent the lifting of damaging overloads while the hoist is being operated. f the load being lifted exceeds the lifting capability of the overload clutch, the hoist motor will continue to run, causing overheating of both the clutch and hoist motor. reducing the load to within the rated capacity of the hoist. ee AR, page 13, for additional instructions on this device. The overload limiting clutch is an emergency protective device and should not be used to measure the maximum load to be lifted, or to sense the overload limiting clutch will protect the hoist from damaging overloads, it will not ensure that a load is within the rated capacity of the hoist. AF OPRATO This hoist is designed for safe operation within the limits of its rated capacity. t is controlled with the 2-button station. Two-speed hoist models have 2-step buttons. The UP or DOW button is pressed to the first step for the slow speed and pressed all the way down for the fast speed. There are many safety features to protect the operator from injury due to failure of the hoist. 2. Do not make extreme side pulls with the hoist. Optional Chain Container Attachment Pin Retainer Clip Figure 3 nstalling Chain Container Assembly Recommended For Use With: tock oist Chain ift hpg. Dimensions in nches o. Capacity in Feet Wt. W 1/ & 1/2 Ton bs. 6 7 /8" 6 1 / / 2 15 BB /2 7 1 /2 20 OT: The Chain Containers listed above are available to keep surplus chain away from work area. Container is suspended from bottom of hoist, and is constructed of liner low-density polyethylene. ncluded with hoist. 67 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Operation (Continued) 3. Operate the hoist only in a hanging position with adequate support.. Do not sling the load hook and chain around the load. Use an approved sling 5. Be sure there are no twists in the load chain as it travels into the hoist housing. This condition should be constantly checked on double chain hoists because it is possible for the load block to be capsized or turned over one or more times. 6. Before raising a load, always check to see that it is held securely in the hook or sling chains, etc. Raise the load only until the load chain is taut and then double check the rigging before continuing to raise the load. 7. Do not stand beneath a load! Do not move a load in such a manner as to endanger personnel. 8. Don t lower into areas where visibility is obscured unless someone else is guiding the operation. 9. Use common sense at all times when operating a hoist. 10. Do not operate if direction of hook travel is not the same as indicated on button being pushed. 11. Do not operate unless hook travel limit devices function. Test without load each shift. 12. Do not operate when hoist is not centered over load. 13. Do not operate if chain is not seated properly in sprockets or sheave grooves. 1. Do not operate damaged or malfunctioning hoist. Do not use hoist to lift, support or otherwise transport people. Troubleshooting Chart ymptom Possible Cause(s) Corrective Action ook fails to stop at end 1. imit switch not operating 1. Check adjustment (see MT WTC ADJUTMT, of travel page 11). Check connections against wiring diagram. Tighten loose connections or replace 2. Brass limit switch nuts not 2. Check for stripped threads or bent nut guide moving on shaft 3. oist reversing contactor 3. Remove electrical cover and check reversing malfunctioning contactor 3. Remove electrical cover and check reversing malfunction in power supply lines 2. Wrong voltage or frequency 2. Check voltage and frequency of power supply against the rating on the nameplate of the motor 3. mproper connections at line connections at line connections at line connections. Brake does not release. Check connections to the solenoid coil. Check for open or short circuit. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 11) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversing contactor 5. Check for proper adjustment (see BRAK ADJUTMT, page 12) 5. Faulty hoist reversi 3YB99 and 3Y10 thru 3Y15 Dayton lectric Chain oists Troubleshooting Chart (Continued) ymptom Possible Cause(s) Corrective Action ook does not stop promptly 1. oist overloaded 1. Reduce load to within rated capacity of hoist 2. Brake not holding 2. Check brake adjustment (see BRAK ADJUTMT, page 11). t may be necessary to replace discs ook moves in wrong 1. Three phase reversal 1. Reverse any two wires (except the green ground direction wire) at the power source (see nstallation 2c, page 5) 2. mproper connections 2. Check all connections against wiring diagram ook raises but will 1. DOW circuit for loose connections. Check DOW not lower limit switch for malfunction 2. Broken conductor in push- 2. Check each conductor in the cable. f one is broken, button cable replace entire cable 3. Faulty hoist reversing 3. Check for burned contacts. Replace as needed ook lowers but will 1. oist overloaded. Overload 1. Reduce load to within rated capacity not raise clutch slipping 2. ow voltage at the reversing contactor is within ±10% of the nominal voltage while lifting a load 3. UP circuit open 3. Check circuit for loose connections. Check UP limit switch for malfunction. Broken conductor in push-. Check each conductor in the cable. f one is broken, button cable replace entire cable 5. Faulty hoist reversing contactor 5. Check coils for open or short circuit, check all connections in control circuit. Check starting capacitor (single phase 6. Faulty capacitor (single phase 6. Faulty capacitor (single phase 6. Faulty capacitor faulty capacitor) and the contact of the context of proper lifting 1. oist overloaded. Overload 1. Reduce load to within rated capacity of hoist speed clutch slipping 2. Brake dragging 2. Check for proper brake adjustment or other defects 3. ow voltage at the reversing contactor is within ±10% of the nominal voltage while lifting a load Motor brake needs adjustment 1. ee BRAK ADJUTMT, page 11 chatter (while starting hoist) 2. ow voltage 2. nsure that the voltage at the reversing contactor is within ±10% of the nominal voltage while lifting a load Motor brake buzz 1. Brake needs adjustment 1. ee BRAK ADJUTMT, page 11 (anytime hoist is running) 2. Broken shading coil on 2. Replace shading coil or complete brake frame brake frame brake frame assembly n all instances, remove load and disconnect hoist from power source. 89 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3YB99 and 3Y10 thru 3YB72 thru 3YB99 and 3Y10 thru 3YB99 and AM tandard B30.16). ome inspections should be made frequently (daily to monthly) and others periodically (monthly to yearly). t is strongly recommended that an nspector s Report, similar to those shown in Figures 12A and 12B, be used and filed for reference. All inspections should be performed or overseen by a designated inspector. pecial inspections should be made following any significant repairs or any operating occurrence leading one to suspect that the hoist s capability may have been impaired. OWR WTOUT POWR f the power fails with a load suspended, the hoist will automatically stop. n an emergency the load can be lowered without power as follows: 1. DCOCT OT FROM POWR UPPY AD RMOV CTRCA COVR. 2. Refer to Figure 8. Open disc brake manually by using two screwdriver blades, one on each side of the brake at a point close to the brake. Do not allow screwdriver blades to touch rotating friction disc C. Do not allow the load to descend rapidly. This causes the motor to race and serious damage may result. 3. Use several quick releases instead of holding brake open continuously. Do not exceed normal lowering speed. OOK Refer to Figure. 1. nspect hooks once daily for cracking, extreme wear or spreading. Replace hooks showing any of these signs. f the throat openings are spread wider than the maximum permissible 15% increase listed here, the hooks have been overstressed and must be replaced. Any hook that is bent or twisted more than 10 degrees from the plane of an unbent hook must also be replaced. 2. The hook latches should be inspected to ensure that they close the hook throat opening in a secure manner when a load is applied. nspect the hook shank and nut for any stripping of the threads or other damage. The hook nut should be fully restrained by the retaining pin. 3. n addition to above, load hooks should be inspected for cracks by the magnetic particle, dye 12). Visually check chain every time hoist is used. oist must not be operated when chain is twisted or kinked. An important phase of hoist maintenance is chain inspection. 1. Check the chain for overall wear or stretch by selecting an unworn, unstretched length of chain (at the slack end for example). et the chain hang vertically with a light load (about 20 pounds) on the chain to pull it taut. Use a large caliper to measure the same number of links in a used section of chain and calculate the percentage increase in length of the worn chain. 2. f the length of the chain to pull it taut. worn chain is more than 1 1 /2% longer than the unused chain (0.015" per inch of chain measured), then the chain is worn more than 1 1 /2%, the chain should be replaced. The chain used on this hoist has very carefully controlled dimensions and has been heat treated. Do not attempt to substitute other manufacturer s chain. ilver ut (Down) old ut (Up) Figure 5 imit witch Assembly pring uide Plate 910 Dayton Operating nstructions and Parts Manual 3YB92 and 3Y10 thru 3YB99 a Replacement Diagram CA RPACMT WT CA OT. Refer to Figure 6 1. Run hook up to its to limit. 2. DCOCT OT FROM POWR UPPY and remove the electrical cover. 3. Using a screwdriver, pry the spring guide plate out of the slots in the limit switch nuts (ee Figure 5). Turn the slotted nut nearest you, the gold nut, back to about the center of the threaded screw. Do not disconnect the wires from the switches.. Remove the load block assembly from old chain. On double -chained hoists it is necessary to remove the chain stripper to detach the chain stripper. 5. Make a C link by grinding through the end link on the load end of the old chain. 6. Use the C link to attach the new chain to the load end of the old chain. (on double - chained hoists it is necessary to pass the C link and attached chain through the chain stripper). Be sure that the welds of the new chain will face outward from the load sheave. The end links must be oriented for attachment to the slack end attachment pin and the chain anchor (double -chained only) without any twist in the chain. 7. With the electrical cover off, connect the hoist to the power supply. Be sure that the green ground wire is properly grounded (see installation, page 5) 8. Carefully jog the UP button and run the joined pieces of chain into the hoist until about 15 of the new chain stop by prying off its retaining ring with a flathead screwdriver. f attached, remove the old chain from the chain stripper by removing the retainer clip and attachment pin. 11. Attach the chain stop to the slack end of the new chain by capturing the 12th link with the two stop halves positioned with their tapered ends pointing ring. f you are not using a chain container, attach the slack end of the new chain to the chain stripper using the attachment pin and retaining clip. DO OT allow twists in the chain. 12. Adjust the lower limit switch (ee ADJUT OWR MT, page 11). 13. Attach the bottom block on single chained hoists, feed the chain through the load block (welds of the upstanding links will be in towards the sheave) and fasten the end of a new chain anchor pin (ee Figure 26) and reassemble the chain. 1. Adjust the upper limit switch (ee ADJUT UPPR MT, page 11). CA RPACMT WT O CA OT. Refer to Figures 6 and 7 1. DCOCT OT FROM POWR UPPY and move hoist to a work table. Do not remove the electrical cover. 2. Detach the chain stripper from the bottom of the hoist. 3. Following the instructions in the section on AR, disassemble the transmission assembly.. Remove the output shaft through the transmission, allowing the load sheave and the bearing on the motor end. OT: nspect chain guides and load sheave for wear, replace as needed. 5. ay the new chain over the load sheave. Allow about 15 of chain below the hoist on the slack end. (ee Figure 6) Be sure the welds of the upstanding links are out away from the load sheave and the proper orientation is observed for attachment of the slack end. Also be sure the load hook assembly (if already attached to the chain) is toward the center of the hoist or to your right looking from the transmission end. 6. Reinstall the chain guide in the housing. 1011 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Maintenance (Continued) 7. Reassemble the output shaft and transmission. 8. Pass the new chain through 1 in the previous section, CA RPACMT WT CA OT, to complete the chain replacement procedure. MT WTC ADJUTMT Refer to Figure 5. MPORTAT: Before placing hoist in operation, check the limit switch adjustment. imit switches are provided to protect the hoist against damage resulting from overtravel or to allow setting the hook travel, the upper and lower limit switch adjusting nuts are color-coded gold and silver respectively. ach limit nut has 10 slots for fine adjustment, and the increment of the limit switch nuts toward or away from each other increases or decreases the hook travel respectively. Care should be exercised when adjusting either limit of travel. ADJUT UPPR MT (OD UT) 1. uspend the hoist. For single chain models raise the load block. Double chain models require a minimum clearance of 1" from the chain support to the top of the load block. 2. DCOCT OT FROM POWR UPPY and remove the electrical cover. 3. With a screwdriver, pry the spring guide plate out of the slots in the limit switch nuts. Turn the slots farther. Release the spring guide plate and be sure it slips back into the slots in both limit switch nuts. Do not disturb the silver slotted nut if it has been set previously. ADJUT OWR MT (VR UT) 1. uspend the hoist. Carefully lower the load block to a point where the slackend loop of the chain hangs down 6" or more from the hoist negative slotted nut if it has been set previously. of 1 1 /2" between the chain stop and bottom of hoist. 2. DCOCT OT FROM POWR UPPY and remove the electrical cover. 3. With a screwdriver, pry the spring guide plate out of the slots in the limit switch nuts.. Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts... Turn the slotted silver nut toward its limit switch nuts.... Turn the slotted silver nut toward its linit switch nut sure it slips back in the slots in both limit switch nuts. Do not disturb the gold slotted nut if it has been set previously. CCK BOT UPPR AD OWR MT 1. Connect the hoist to the power supply. Be sure the green ground wire is properly grounded (ee nstallation 2-b, page 5). 2. Check load hook direction (ee nstallation 2-c, page 5). 3. Carefully raise load block to upper limit and observe if it stops automatically at desired level. Do not allow load block to run into hoist housing and the top of the load block on single-chained models and 1" from the chain support to the top of the load block on double-chained models. Carefully lower load block to lower limit and observe if it stops automatically at the desired level. Do not allow slack-end loop of chain to become taut against hoist. 5. f upper and lower limits operate satisfactorily, hoist is ready for use. f they are not as desired, repeat adjustment. f the wires running to the limit switches are ever disconnected for any purpose, be sure to replace wires in accordance with the correct wiring diagram (ee Figures 11A, 11B, and 11C). BRAK ADJUTMT Refer to Figure 8. Properly adjusted, this brake will release promptly when energized. t is capable of both smoothly stopping and securely holding the rated capacity of the hoist. f the hoist develops either undesirable in the lowering direction) or hesitates to lift the load promptly when the pushbutton is most noticeable in the lowering direction. the hoisting direction), the brake should be adjusted as follows. B ap A X D Figure 8 Brake Assembly F X C 1112 Dayton Operating nstructions and Parts Manual 3YB99 and 3Y10 thru 3YB99 and 3Y the gap between the brake armature A and the field B should be checked. The correct gap is 0.015". Adjustment should not be necessary until gap reaches 0.00". 3. Adjust gap by adjusting the 3 locknuts F and checking with a feeler gauge to be sure gap is the same on both ends of the solenoid. Be sure the bottom of the armature does not bear against the splined adapter. As adjustments are made, the built-in clearance will be reduced. When this clearance is gone RPAC BRAK DC. Minimum allowable disc thickness is 162"... Adjustment is now complete and the brake properly set. Replace the electrical cover, reconnect the power supply, and check hoist brake action. COTROR Both the pushbutton and the reversing contactor are mechanically interlocked to prevent shorting the circuit and causing serious damage. As part of maintenance, always check for proper closure of contacts. I replacement is necessary, see Figures 21, 22, 2, and 25 for repair parts. WR Refer to Figures 11A, 11B and 11C ingle-phase units (115/230V) are shipped wired for 115V and the 1-speed, three phase units (230/60V) are wired for 60V. Two-peed hoists to either the higher or lower voltage can be done simply and quickly as follows: 1. DCOCT OT FROM POWR UPPY and remove the electrical cover. 2. ach dual-voltage hoist has a terminal block for the interconnection of the electrical convert voltage, reconnect the leads to the terminal block. 3. After converting diagram located inside the electrical cover. Do not move any wires or make any changes to the terminal block. voltage, recheck phasing and limit switch operation (ee nstallation 2-c &, pages 5 & 6). MPORTAT: Always refer to the wiring diagram located on the inside of the electrical cover when performing electrical repairs. Make sure all terminals are securely fastened and check for damaged insulation. UBRCATO Refer to Figure 13. Proper lubrication is necessary for a long and relatively trouble-free hoist operation. Refer to the following and the RCOMMDD UBRCATO CDU for lubrication. OAD CA. Clean the load chain with acid-free solvent and coat with A 90 gear oil. Wipe excess oil to prevent dripping. ever apply grease to the chain. AR. The gear case of this hoist is filled at assembly with approximately 1 1 /2 pints of A 90 P gear oil should be even with the hoist. With the hoist hanging level, gear oil should not require additional lubrication. oisy or worn bearings should be replaced. MT WTC AFT. Remove any dirt accumulation and spray with a general purpose lubricant. OOK BAR. Apply a few drops of A 30 gear or motor oil around the edge of the bearing. DR AV BAR (BU). Disassemble load block and apply a light coat of #2 grease, or equivalent, inside of bearing OT RPAR 1. For major repairs or when the hoist is to be sectioned in the suspension area, it will be necessary to move the hoist to a workbench or table. 2. For repairs which can be done by removing the electrical cover only, the hoist need not be moved. owering the hoist to a convenient working level is desirable. OT: f you do not have an experienced mechanic to do your repair work, we recommend that you send your hoist to an approved service station for repairs. Use authorized repair procedures, when related to the Repair Parts ist starting on page 18. For clarity these are broken down into areas. CTRCA PART AD BRAK Refer to Figures 11A, 11B and 11C. 1. Remove the electrical cover. The control panel, brake assembly, and limit switch assembly are located under the cover. The control panel block are accessible without further disassembly. t will be necessary to remove the electrical panel to replace the transformer, solenoid, limit switches, or brake parts. 2. Remove the electrical panel to the back of the panel plate if it requires replacement. 3. With the electrical panel taken off the limit switch and brake are exposed. Figure 9 shows this area with the panel removed. 1213 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Maintenance (Continued). Refer to Figure 23 to disassemble the brake. ee BRAK ADJUTMT to properly set the brake. 5. Refer to Figure 20 to disassemble the limit switch. ee MT WTC ADJUTMT to properly set the upper and lower limits of travel. 6. Refer to Figures 2 and 25 for repairs on the pushbutton station. Also refer to Figures 16, 17, and 18. The hoist motor is located on the opposite end to that of the electrical parts, but the two are tied together with electrical leads running through the housing. 1. f it is necessary to replace or repair the motor, DCOCT T OT FROM T POWR UPPY and remove the electrical leads running through the housing. electrical section (ee Figures 21 and 22). 3. Remove the four motor coupling, motor shaft and all the bearings. Replace as necessary. 5. nstall new or repaired motor according to the wiring diagram located inside the electrical cover. AR Refer to Figures 10, 15 and 19. As disassembly is extensive for gearing, disconnect the hoist and move it to a workbench. 1. Remove the electrical cover. 2. Remove the four screws that attach the gear box cover to the gear housing and remove the gear box cover. The limit switch drive shaft will come along with the cover. 6. nspect gears for broken or severely worn teeth and must not be disassembled or readjusted. Do not disassemble or readjust the clutch, or interchange it with a clutch assembly from another hoist. Doing so will void the warranty and may create an unsafe condition. f replacement is needed due to wear or loss of adjust-ment, always use a new clutch assembly. Figure 10 - Assembled earing 7. Reassemble in reverse order of disassembly, making sure that the gasket is in place and in good condition. Coat the gasket with Permatex or other gasket cement. xtreme care should be taken to avoid damage to oil seals. 8. Check all wire terminals to be sure that they are properly seated and in accordance with the correct wiring diagram. Before placing the hoist back into service, check the brake adjustment and limit switch settings. UPO (ee below) Periodic inspections of the top suspensions can be made without disassembly. For more extensive inspections the top hook retaining screw. 3. Remove the top hook retaining screw. 3. Remove the top hook retaining screw. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 2. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 2. Remove the top hook retaining screw. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 2. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 2. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 2. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove it to workbench. 3. Remove the top hook is follows: 1. Disconnect the hoist and remove the top hook is follows: 1. Disconnect the hoist and remove the top hook is follows: 1. Disconnect the hoist and the hook is follows: 1. Disconnect the hoist and the hook is follows: 1. Disconnect the hook is follows: 1. proper orientation. Refer below for proper orientation. ingle Chain Double Chain Figure 11 - uspension The transmission must be disassembled in order to Figure 19 and 2. When reassembled, recheck the limit switch settings. ee MT WT ADJUCTMT, page14 Dayton Operating nstructions and Parts Manual 3YB72 thru 3YB91 and 3YB96 thru 3YB99, 3Y10 and ZY5 thru 3YB99, 3Y10 and ZY5 thru 3YB99, 3Y10 thru 3Y15. For oists with VFD(Variable Frequency Drive) control units refer to Multi-Vector VCP Manual included with oist. Figure 11B Wiring Diagram for 1-peed, 3-Phase Models 3YB80, 3 nstructions and Parts Manual Models 3YB92 thru 3YB95 and 3Y11 thru 3Y15 and ZY5 thru 3YB95 & 3Y11 thru 3Y15. For oists with VFD (Variable Frequency Drive) control units refer to Multi-Vector VCP Manual included with oist. Power upply Precautions with 1-Phase oists lectric hoists require a sufficient power source are adequate in size to handle the power source are adequate in size to handle the power source are adequate power source are adequate power source are adequate power source are adequate in size to handle the power source are adequate power source ar amperage, damage to the hoist, and potential fire hazards. uch problems can be minimized by using 230V power on 115/230V hoists. The following are recommendations for the conductor gage size depending on the length, horsepower, and voltage. Maximum Conductor ength in Feet P Voltage 1 AW 12 AW 10 AW 8 AW (1-Phase) 1/2 115V V V V16 Dayton Operating nstructions and Parts Manual 3YB99 and 3Y10 thru 3YB99 and 3Y10 thru 3Y15 Dayton lectric Chain oists Maintenance (Continued) Type of oist ocation Manufacturer PCTO AD MATAC CCK T CTRC POWRD OVRAD CA OT Capacity (Tons) Original nstallation Date Manufacturer s erial o. tem Frequency of nspection Possible Deficiencies OK Action Required Frequent Periodic Daily Monthly 1-12 Mo. Operating controls * * * 1. lippage or excessive drift 2. lazing, contamination or excessive throat opening 15% bent or twisted more than 10 degrees, damaged hook latch, wear, chemical damage, worn hook bearing. Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks, excessive wear or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (use dye penetrant, magnetic or other suitable detection method) * * * Cracks (u detection method) Chain * * * nadequate lubrication, excessive wear or stretch, cracked, damaged or twisted links, corrosion or foreign substance ook and uspension ug Connections * Cracks, bending, stripped threads Pins, Bearings, Bushings hafts, Couplings * xcessive wear, corrosion, cracks, distortion uts, Bolts, Rivets * ooseness, stripped and damaged threads, corrosion heaves ousings, oad Block * Distortion, cracks, and excessive wear. Build-up of foreign substances * Cracks, distortion. xcessive wear, internal build-up of foreign substances * Cracks, distortion. contacts Apparatus upporting tructure and Trolley Damage or wear which restricts ability to support (if used) * imposed loads ameplates, Decals, Warning abels * Missing, damaged or illegible OT: Refer to Maintenance and nspection ections of the oist-maintenance and nspections of the oist-maintenan inspection daily to monthly. Daily inspections may be performed by the operator if properly designated. Periodic ndicates items requiring inspection monthly to yearly. nspections may be performed by or under the direction of this period will be based on the user s experience. t is recommended that the user begin with a monthly inspection and maintenance Check list is in accordance with our interpretation of the requirements of the afety tandard for Overhead oists AM B t is, however, the ultimate responsibility of the employer/user to interpret and adhere to the applicable requirements of this safety standard. 1617 Dayton Operating nstructions and Parts Manual Models 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Maintenance (Continued) TM PCTOR RPORT RMARK (T DFCC AD RCOMMDD ACTO) nspector s Date ignature nspected Approved by Date Figure 12B Recommended nspector s Report RCOMMDD UBRCATO CDU* DAYTO CTRC POWRD CA OT PA AD COMPOT TYP OF UBRCATO Pages 32 & 33 o. 18 AVY ORMA FRQUT oad Chain A 90 gear oil Daily Weekly Monthly Pages 22 & 23 earing tock o. F979 or At periodic inspection (see Figure 12A) A 90 extreme pressure (P) gear oil Page 2 o. 9 imit witch haft Dayton Dem-Kote o. 5X628 multipurpose oil or general purpose spray Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Pages 32 & 33 o. 38 & 50 oad ook Bearing A 30 gear or motor oil Weekly Monthly Yearly Y Monthly Yearly Pages 32 & 33 o. dler heave Bearing (Bushing) Assembly tock o. ZF6 #2 multipurpose lithium At periodic inspection (see Figure 12A) base bearing grease OT: All bearings are prelubricated and sealed. (*) This lubrication schedule is based on a hoist operating in normal environment conditions oists operating in adverse atmospheres containing excessive heat, corrosive fumes or vapors, abrasive dust, etc., should be lubricated more frequently. Figure 13 Recommended ubrication chedule 1718 Dayton Operating nstructions and Parts Manual 3YB72 thru 3YB99 and 3Y10 thru 3Y15 For Repair Parts, call hours a day days a year Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts ist for Basic oist Repair Parts ist for Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts ist for Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts ist for Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Figure 15- Basic oist Repair Parts P.O. Box hermer Road orthbrook, U.A OT: FUR 11 FOR CORRCT OOK ORTATO Cover screw 2976P 7 3 Trim cover JM37 1 Transmission housing JM Transmission cover JM37 1 Transm JM675K /2 ton Capacity decal JM675K ton Capacity decal JM675K ton Capacity decal JM675K ton Capacity decal JM675K-20 1 ylon cover for 1/ ton 08773W 1 ylon cover for 2 ton 0877W 1 Chain container 0838W 1 () ot hown () Optional 1819 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB72, 3YB78, 3YB79, 3YB83, 3YB83, 3YB83, 3YB87, 3YB87, 3YB87, 3YB87, 3YB87, 3YB87, 3YB87, 3YB90, 3YB91, 3YB96 thru 3YB99 & 3Y10 1 Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A) Refer to the motor nameplate for part number voltage, full load amperage, horsepower, and other motor information. 3 6 Figure 16-1-ingle-Phase Motor 2 Repair Parts ist for 1-peed, ingle Phase o. DescriptioPart Description o Part o. 1/2 Qty..P. Qty. 1 1-speed motor, complete 1/2 hp Motor 1 hp Motor 1 115/230V, 60 z 861JM12 861JM1 2 tato assembly 1 3 Rotor assembly 1 nd shield 35P3100D15 35P3100D15 35P3100D Rear bearing 500K3 1 6 Front bearing C C 1 7 him washer J J Thru bolt A3100A56 A3100A56 A3100A56 9 #10 pring lockwasher 082P () ot available as an individual part. Complete motor must be purchased. 1920 Dayton Operating nstructions and Parts Manual For Repair Parts, cal hours a day days a year 3YB73 thru 3YB77, 3YB80, 3YB82, 3YB86 and 3YB89 1 Please provide following information: -Model number voltage full load amperage, horsepower, and other motor information Figure 16-1-peed, Three-Phase Motor 1 230/60V, 60 z 863JM 2 tator assembly 1 3 Rotor assembly 1 3 Rotor assembly 1 and shield 35P3100D15 35P3100D Rear bearing 500K3 to 2 863JM 2 tator assembly 1 and shield 35P3100D15 35P3100D Rear bearing 500K3 500K3 1 6 Front bearing C C 1 7 him washer J J Thru bolt A3100A15 A3100A15 9 #10 pring lockwasher 082P () ot available as an individual part. Complete motor must be purchased. 2021 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB92 thru 3YB95 and 3Y11 thru 3Y15 1 Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U..A () Refer to the motor nameplate for part number voltage, full load amperage, horsepower, and other motor information Figure 18-2-peed, 3-Phase Motor Repair Parts ist for 2-peed, 3-Phase Motor o Description Part o. Qty. 1 1-speed motor, complete 1/2 hp Motor 1 60V, 60 z 873JM6 873JM8 2 tator assembly 1 a Rotor assembly 1 3 Rotor assembly 1 3 Rotor assembly 1 a Rotor 1 60V, 60 z 873JM6 873JM8 2 tator assembly 1 a Rotor assembly 1 a Rotor assembly 1 a Rotor 1 60V, 60 z 873JM6 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rotor 1 60V, 60 z 873JM8 2 tator assembly 1 a Rot 082P () ot available as an individual part. Complete motor must be purchased. 2122 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U..A *18 *16 3YB72 thru 3YB99 and 3Y10 thru 3Y15 *19 11 *20 1 * ** (*) OT: This stage of gearing is not required on 32 FPM models. (**) OT: Orient output gear (33) with long boss towards transmission cover. 2 Figure 19 - earbox 2223 Dayton Operating nstructions and Parts Manual Repair Parts ist 3YB72 thru 3YB99 and 3Y10 thru 3Y15 Repair Parts ist for earbox Part o Description o. Qty. 1 heave housing JM Transmission gasket JM Transmission gasket JM Transmission cover JM3 1 (includes oil seals) pring washer 360J1 1 5 O-ring Pressure relief fitting K W 1 7 Chain uide JM Oil plug- Evel Oil seal 561K crew, welf-threading 2693P 5 13 Motor coupling JM Bearing 500K nput pinion for 8 & 16 fpm J Retaining ring Brake adapter J Bearing for 8 & 16 fpm J Retaining ring Brake adapter J Bearing for 8 & 16 fpm J Netrona clutch assembly for 1/ ton, 16 fpm J Netrona clutch assembly for 1 16 fpm 591J25 1 1/ ton, 32 fpm 591J22 1 1/2 ton, 16 fpm 591J16 1 1/2 ton, 32 fpm 591J & 2 ton 591J Retaining ring Bearing 500K Bearing P pacer-oad sheave JM Oil seal Retaining ring Output gear J Dowel pin ear oil /2 pt () ot shown. 2324 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB72 thru 3YB99 and 3Y10 thru 3Y15 1 Please provide following information: -Model number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A Figure 20 - imit witch Assembly Repair Parts ist for imit witch Assembly 0. Description Part o. Otv. 1 Transmission cover IM3 1 2 imit switch assembly 91813 1 (includes items -8) witch 8151 UC X 1" crew 102P UC lastic locknut 39 7 imit switch bracket IF (includes item 8) 8 Bushing IF531-1 o. Description Part o. Otv. 9 imit switch shaft JF imit switch nut (silver) K Z 1 11 imit switch nut (gold) K W 1 12 Retaining ring nsulator JF pring JF UC X 1/2" crew25 Dayton Operating nstructions and Parts, call hours a day days a year 3YB72 thru 3YB91 and 3YB96 thru 3YB99, 3Y Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A Figure 21 - lectrical Parts, 1-peed Models 8 Repair Parts ist for lectrical Parts, 1-peed Models 8 Repair Parts ist for lectrical Parts, 1-peed Models Part Parts ist for lectrical Parts for 1-peed Models 8 Repair Parts ist for lectrical Parts, 1-peed Models 8 Repair Parts ist for lectrical Parts for 1-peed Models 8 Repair Parts ist for lectrical Parts, 1-peed Models 8 Repair Parts ist for lectrical Parts ist for lectrical Parts ist for lectrical Parts for 1-peed Models 8 Repair Parts ist for lectrical Parts ist for contactor for 1 hp, 115/230V hp, 230/60V /2 hp Only Transformer for Pri.: 115/230V, ec.: 2V 821J Terminal block for 115/230V, 909J /230V, 230/60V 909J nd clamp 909J Marking strip 909J ft Power cord assembly for 115/230V, 1/2 (3 cond.) 951J /230V, 1 hp (3 cond.) 952J /60V (cond.) 953J PB & cable assembly (ee Figure 2) 1 12 Panel standoff spacer 200J /" nternal-tooth lockwasher /-20UC X 1/2" crew Can mounting bracket JM PAC tarting witch 839J Capacitor 1 p motor J /2 p motor nstructions and Parts Manual For Repair Parts, call hours a day days a year YB92 thru 3YB95 and 3Y11 thru 3Y15 and ZY5 thru ZY65 Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A. Figure 22 - lectrical Parts for 2-peed Models, For oists with VFD (Variable Frequency Drive) control units refer to Multi-Vector VCP Manual included with oist. Repair Parts ist for lectrical Parts, 2-peed Models (60V) o. Description Part o. Oty. 1 Transmission cover IM3 1 8 Panel standoff spacer 200] 3 2 Panel plate 257IM /" nternal-tooth lockwasher Reversing contactor for 10 1/-20UC X " crew 1027P 3 1 hp UC X 5/16" crew /2 hp #8 xternal-tooth lockwasher peed control relay for 13 1/" Flatwasher 002P 1 1 hp UC X 5/16" crew /2 hp md clamp 909] Transformer 821] Multi-Vector VCP (oist with VCP Only) Pri.: 230/60V, ec.: 2V Refer to Manual included with oist for operation 6 15 ft Power cord assembly 953J1 1 instructions.) 7 PB & cable assembly (ee Figure 25) 1 2627 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB72 thru 3YB99 and 3Y10 thru 3Y Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A Figure 23 - Brake Assembly for 1-phase 85[M1 1 3-phase, 1-speed 85[M2 1 3-phase, 2-speed 85[M3 1 2 Plate & stud assembly 859[1 1 3 Brake Disc 581[1A 3 Brake plate JF Plate & armature assembly JF pring 3J6 3 7 Retaining ring hading coil adhesive ockwasher 13 3 OT: Refer to the wiring diagram inside the electrical cover or Figures 11A, 11B, or 11C when connecting any wires. 2728 Dayton Operating nstructions and Parts Kanual For Repair Parts, call hours a day days a year 3YB72 thru 3YB91 and 3YB96 thru 3YB99, 3Y10 Please provide following information: -Model number -erial number (if anv) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A Figure 2-1-peed Pushbutton tation 2829 Dayton Operating nstructions and Parts Nanual Repair Parts ist 3YB72 thru 3YB91 and 3yb96 thru 3YB99, 3Y10 Repair Parts ist for 1-peed Pushbutton o. Description Part o. Qty 1 Pushbutton station & control cable assembly for 6 ft Cable length PB Button assembly rommet * ardware kit (includes items 9-16) Warning tag 687K3W 1 (#) gual to cable length. () ot shown. 2930 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB92 thru 3YB95 and 3Y11 thru 3Y15 Please provide following information: -Model number -erial number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A Figure 25-2-peed Pushbutton tation 3031 Dayton Operating nstructions and Parts Nanual Repair Parts ist 3YB92 thru 3YB95 and 3Y11 thru 3Y15 Repair Parts ist for 2-peed Pushbutton o. Description Part o. Qty 1 Pushbutton station & control cable assembly for 6 ft Cable length PB f Button assembly rommet * ardware kit (includes items 9-16) Warning tag 687K3W 1 (#) qual to cable length in feet. () ot shown 3132 Dayton Operating nstructions and Parts Manual For Repair Parts, call hours a day days a year 3YB72 thru 3YB99 and 3Y10 thru 3Y Please provide following information: -Model number (if any) -Part description and number as shown in parts list Address parts correspondence to: rainger Parts P.O. Box hermer Road orthbrook, U.A /, 1/2 & 1-Ton Models Ton Models Figure 26 - Chaining Parts 32